


## Scoreboard /



POWER SWITCH  
OFF

## Control box

Display window >>>>>

**AUTO HORN** 

**HOME** **GUEST**

PENALTY <	PLAYER • PENALTY
SHOTS ON GOAL •	SHOTS ON GOAL +1
SCORE •	SCORE +1

ENABLE PENALTY CLOCKS	DISABLE PENALTY CLOCKS
PERIOD •	PERIOD +1

PLAYER >	PLAYER • PENALTY
SHOTS ON GOAL •	SHOTS ON GOAL +1
SCORE •	SCORE +1

7	8	9
4	5	6
1	2	3
CLEAR NO	0	ENTER * YES

**MENU**

COUNT UP/DOWN

SET MAIN CLOCK

**START**

**STOP**

## Time Clock - Basic Instructions

Report to the bench area five minutes before game time.

Turn the time clock on using the rocker switch on the backside of the control box.

### Set clock for pre-game warm-up

1. Push **SET MAIN CLOCK**
2. Set clock for five (5) minutes.
3. Push **ENTER\*YES**
4. Push **START** once both teams are on the ice.
5. Horn will sound automatically at end of set time

### Set main clock to begin each period

1. Push **SET MAIN CLOCK**
2. Set clock for total minutes to be played in the period
3. Push **ENTER\*YES**
4. Push **PERIOD +1** to add a period

When the official is ready to drop the puck and start a period, he/she will check with both goalies and you to ensure your ready.

**STOP the CLOCK** when the whistle blows, using the remote button or the **STOP** button on the clock control

When the official is ready to face off, he/she will blow whistle to signal play is about to begin.

**START the CLOCK** when the puck hits the ice using the remote button or the **START** button on the clock control

### Recording a goal

1. Make sure to **STOP the CLOCK** when the whistle blows
2. Push **SCORE +1** for the appropriate team
3. Get ready for the face off at center ice

### Recording a penalty

1. Make sure to **STOP the CLOCK** when the whistle blows
2. Push **PLAYER PENALTY** for the appropriate team
3. Push **ENTER\*YES**
4. Enter the player number (optional)
5. Push **ENTER\*YES**
6. Enter the number of penalty minutes assessed as reported by the official.
7. Push **ENTER\*YES**
8. Look up at the clock and the penalty should be showing. If not, go back to #2 and do it again.
9. Get ready for the face off
10. Penalty time will start/stop with the main clock

### Clearing a penalty

1. Make sure to **STOP the CLOCK** when the whistle blows
2. Push **PLAYER PENALTY** for the appropriate team
3. Push **ENTER\*YES**
4. Use the arrow up button to scroll to player
5. Push **Clear / NO**
6. Push **ENTER\*YES**
7. Look up at the clock and make sure that the penalty is removed. If not, go back to #2 and do it again.
8. Get ready for the face off

### Notes:

- The number of minutes played varies by level and tournament rules.
- 1/10<sup>th</sup> minute may be represented on the clock. The window on the clock control displays how the data will be displayed on the scoreboard.
- Most scoreboard controls have a remote with clock start/stop switch and horn button
- Typically, there is an instruction sheet located near the scoreboard control.
- Using the clock to track the time between periods is optional in most games.
- Dress warmly!