

BASIC SCORE CLOCK OPERATION

TO SET TIME:

1. Press SET; then TIME. Now enter the desired time. If it is a single digit time, then you must enter a 0 before the time for minutes and after for seconds. (For example- 5 minutes – enter as 05:00.0 seconds.)
2. Next it will ask if this is the correct time; press YES.
3. Enter period- press period number (1 2 3)

ADDING GOALS:

Press HOME or GUEST Score; then 1

To correct a score, press SET; then press Home or Guess score; then press the correct number

SHOTS ON GOAL:

HOME and GUEST Shots operate the same as the directions for adding goals

DISPLAYING BASIC PENALTIES (1 or 2):

Press SET; then HOME or GUEST Penalty, Put in the length of the penalty (you must enter the 0 before and after the minutes of a minor penalty)
Press YES, Enter Player # (single digits enter a 0 first)

ENTERING MORE THAN 2 PENALTIES (up to 5)-

If the team already has 2 penalties and a 3rd penalty is called, enter as normal. When the first penalty runs out, the third will automatically start. The player of the first penalty cannot return to the ice until the second penalty is up because it is a stacked penalty and there are already 3 players on the ice.

If there are more than 5 penalties, you must keep track on paper.

CLEARING A PENALTY:

Press HOME or GUEST Penalty Key until the penalty you want to clear is displayed. Press PENALTY CLEAR and answer YES
